





Elevated interactive experience with smart display and OMNI 2.0.



interpretation.

Customizable lanyards bring portability and express user's individuality.



iKraft available: efficient, fast, and cost-effective customization.

Button activation, for even heating,

flavor burst, and ultimate terpene



Real postless design ensures safe and reliable flavor. Illuminated tank visualizes oil quality.



Stand-up charging design avoids potential oil leaking and waste.

Recommended Oil Types

Live Resin, Distillate

Certifications & Lab Tests



MSDS



Heavy Metal Test

K

VATRA PRO TC



Technical Specifications

Max Fill Volume	1.0 mL 2.0 mL		
Weight (Empty)	20.2 g (1.0 mL) 19.9 g (2.0 mL)		
Mouthpiece Capping Method	Snap-on A press machine is recommended for large batches.		
Activation	Button Activated		
Battery Capacity	265 mAh		
Output Power (Customizable by OMNI App)	Low (Default) : 2.1-0.9 W High: 2.9-1.4 W		
	2.1W 1.8W 1.6W 1.4W 1.2W 1.0W 0.9W 0.9W Low 2.9W 2.6W 2.3W 2.1W 1.8W 1.6W 1.4W 1.4W 1.4W 1.4W 1.4W 1.4W 1.4W 1.4		
Atomizer Resistance	1.4 Ω±0.1 Ω		
Aperture	5.3*1.5 mm		
Charging Port	USB Type-C		
Key Components Material	Mouthpiece: Food Grade PC Tank: Medical Grade PCTG Heating Element: iKonic Flux Ceramic Coil Battery Shell: PC		
Customization Capability	Atomizer Resistance Modification Customized Logo, Color, and Surface Finish Customized Oil Window, Mouthpiece, and Lanyard		

Temperature Curve Modification

VATRA PRO TC

Display Illustration







Oil Level Sign



Oil Sign



Parameter Reading



Battery Level

Power Level






Oil Level



75%













The oil and oil level sign will flash 5 times before the display off

Operation Instructions*

Function	Instruction	Display	Indicator (At the bottom of the tank)
Start	& 5 Presses	The display shows power, oil, and battery levels.	- <u>`</u> ⇔́- On
Off	& 5 Presses	The display will be off.	-,̇҉ o ੍ਰੰ- On
Actuation	& Press	The display shows power, oil, and battery levels.	- <u>`</u> ó;- On

	Pre-heat	见 2 Presses	The display will light up in a rolling marqueen sequence.	- <u>`</u>	On
	Switch the Temperature Modes	见 3 Presses		- <u>`</u>	On
	Customize the Temperature Curve via OMNI 2.0	Tap the device to a smartphone with the OMNI app and adjust the curve as you desire.	On 3 s	- <u>`</u>	On
	Customize the Temperature Curve via OMNI 1.0	Connect the device to an OMNI HUB and a smartphone with the OMNI app and adjust the curve as you desire.	On 3 s	- <u>`</u>	On
	Charging	[好] Plug in	 Battery sign flashing: Charging Battery sign stops flashing, display off after percent sign on for 300s: Fully charged Battery sign flashing 3 times: Charging discontinued 	©	Off
_	Low Battery	은 Press	The display off after battery sign flashing 5 times.	- <u>`</u>	Flashing 5 times
	Overdose Protection	& One Puff > 10s	The display off.	0	Off
	Short-circuit Protection	& Press	The display off after battery sign flashing 7 times.	0	Off